






















Installation Instructions Flexseal Couplings

Standard Coupling (SC) Large Coupling (LC)	Drain Coupling (DC)	Adaptor Coupling (AC)	Instructions
			<p>Loosen the clamp bands and slide the coupling onto the first pipe. <i>No lubricant required.</i> *AC - Smallest pipe first.</p>
			<p>Make a mark on the second pipe, half a coupling's width from the end to be jointed.</p>
 			<p>Insert the second pipe up to the mark.</p>
 			<p>Tighten the clamp bands to the recommended torque in sequence across the width of the coupling. *SC & LC- Start with the central shear band.</p>
			<p>Tamp the bedding under the pipe and re-tighten prior to backfilling.</p>

Installation Instructions Flexseal Bush

Standard Coupling (SC)/Large Coupling (LC) & Bush (BC)	Instructions
	<p>Measure the couplings' width and mark both pipes half the couplings' width from the end to be jointed.</p>
	<p>Slide the bush onto the smallest pipe, up to the marked point.</p>
	<p>Loosen the clamp bands and slide the coupling onto the larger pipe. <i>No lubricant required.</i></p>
	<p>Insert the smaller pipe up to the mark.</p>
	<p>Tighten all of the bands on the coupling to the recommended torque in sequence across the width of the coupling, starting with the central shear band.</p>
	<p>Tamp the bedding under the pipe and re-tighten prior to backfilling.</p>